## Week 5

- 5.1 Learn the basic of sharedpreference from Youtube video
- 5.2 Create a highscore app (Try yourself)
  - 5.2.1 One EditText
  - 5.2.2 One Button
  - 5.2.3 Input a new score in EditText and then click a button, Toast will show a new score as "high score = xxxx" if it is higher than the current score in the sharedpreference. Otherwise, Toast will show "No new score".

## เฉลย 5.1

```
public class MainActivity extends AppCompatActivity {
Button btn;
EditText edt;
@Override
protected void onCreate(Bundle savedInstanceState) {
  super.onCreate(savedInstanceState);
  setContentView(R.layout.activity_main);
  btn = (Button)findViewById(R.id.button);
  edt = (EditText)findViewById(R.id.editText);
  final Context context = getApplicationContext();
  final SharedPreferences sh = getSharedPreferences("myShared", context.MODE_PRIVATE);
  final SharedPreferences.Editor editor = sh.edit();
  editor.putInt("highScore",0);
  editor.commit();
  btn.setOnClickListener(new View.OnClickListener() {
     @Override
     public void onClick(View v) {
       int inputScore = Integer.parseInt(edt.getText().toString());
       int currentScore = sh.getInt("highScore",-1);
       if(inputScore > currentScore){
         Toast t = Toast.makeText(context,"High score = "+inputScore,Toast.LENGTH_LONG);
         t.show();
         editor.putInt("highScore",inputScore);
         editor.commit();
       }
       else
         Toast t = Toast.makeText(context,"No new score",Toast.LENGTH_LONG);
         t.show();
       }
  });
```

}			